



S t r a t a F u r n i t u r e
Adriana

AD 0306


1A Parts in Box 1



Arm- outside view




Arm- inside view




Advance Arms **x 2**

1B Parts in Box 2




Back Deck **x 1**




Seat Deck **x 1**
with the Feet attached


1C Parts in Box 3



Back Panel **x 1**



Stretcher **x 1**




Foot Connector
 Bar **x 1**

S t r a t a F u r n i t u r e


Adriana

AD 0306

2A Hardware in this Box:



Bolts (100mm) **x 8**
*for the Stretcher
and Back Panel*




Bolts (60mm) **x 6**
*For the Advance Arms
and the Foot Connector Bar*




Thumb Nuts
x 2




Barrel Nuts
x 6




Wood Button
x 8



Long Clevis Pins
x 2




Short Clevis Pins
x 2



Washers
x 10




Locking Pins
x 4




Plastic Runner
x 2



Sleeve
x 2



Screw
x 4



Strap **x 1**



Bungies
x 2




Long Allen Key
x 1

Strata Furniture *Adriana*

AD 0306

3A Assemble the Back Panel between the Arms.



Bolt the parts together with using the Bolts and Nuts as shown in the drawing. It is helpful to keep the frame squared. Be patient, it can be tricky to start the bolts in the nuts - a screwdriver will help you line up the Barrel Nut with the Bolt.


Drive the Bolts in until they just catch the Nuts.

It is important that these bolts are left loose !

Strata Furniture Adriana

AD 0306

4A Assemble the Stretcher between the Arms.




Fit the Stretcher between the Arms. Bolt the parts together with four long Bolts (100mm) and Barrel Nuts.


Drive the Bolts in until they just catch the Nuts.

It is important that these bolts are left loose !

4B Attach the Advance Arms to the Arms



The slotted end of the Advance Arm attaches to the little wood block at the back of the Arm. Slip a washer and Sleeve over the Bolt, and pass it through the slot. Add another washer and fix it to the Arm. Tighten the Bolt. Be sure that the Advance Arm moves freely. Rotate so that it is pointing up.




S t r a t a F u r n i t u r e
Adriana

AD 0306

5A Join the Seat and Back Deck together.

Lay both Decks out flat on the floor with the stickers facing upwards.


The Seat Deck fits inside the Back Deck as shown. Slip the Long Clevis Pin through the small end of the Plastic Runner, through the hole in the Back Deck and the corresponding hole in the Seat Deck. Secure with a Washer and Locking Pin.



Strata Furniture Adriana

AD 0306

6A Attach the Connector Bar to the Legs.




Lift the Seat Deck so it resting on the Back Deck.
The feet should be pointing downwards.

Line up the holes between the Connector Bar and the
Legs. Make sure the recess for the head of the Bolt is
facing outwards.

Use four short Bolts (60mm) and bolt it in place.

6B Assemble the Bungies under the Seat Deck.



Screw the Bungies to the side of the two inner
rails. Fix the lower end of the Bungie chord first,
then stretch the Bungie over the Connector Bar.
Fix the top end.



Strata Furniture Adriana

AD 0306

7A Fit the Seat and Back Decks to the Frame.





Insert the decks into the partially completed frame. This is where a helper may be useful. When the guides are in the grooves in the Arms, slide the assembly to the back of the frame.

Tighten all Stretcher and Back Panel Bolts.

7B Connect the Advance Arms to the Arms.

Secure with a Washer and Locking Pin.



7C Fit the Strap to the Back Deck.




Strata Furniture Adriana

AD 0306

8A Fit the Wood Buttons to the Arms.

Finally, when the frame is fully assembled, make sure all the bolts are secure.

Push fit or lightly tap the Wood Buttons into the bolt holes on the Arms



Note: *Never lift the frame by the arm caps - Always lift from the bottom of the arms.*

Operating Instructions: *To convert into couch position:*

- Remove any pillows and other obstructions. Reach to the back and lay the strap on top of the mattress.
- Lift up the seat deck into a vertical position.
- Resting seat deck on your hip, push the foot connector down all the way so that the foot connector touches the side rail - *It is Very Important* that the feet are in proper position - see diagram.

Correct Foot position



- With one hand lightly push the seat deck down and with other hand pull the back using the Strap, making sure that the mattress clears back rail. Push the seat deck in all the way.
- **DO NOT FORCE** - the frame should operate easily.

Operating Instructions: *To convert into bed position:*

- Lift up the seat deck into a vertical position.
- Resting seat deck on your hip, rotate the foot connector towards you until the feet are fully extended.
- Set the frame down gently.